


PSD-3-152/a


WATER PRODUCTS COMPANY


COMMERCIAL POWER BURNER BOILER REPLACEMENT PARTS LIST

COPPER BOILERS FOR HYDRONIC HEATING & HOT WATER SUPPLY LEGEND MODELS LB/LW: 1000 SERIES 300, 301













CONTROLBOARD See page 7




JACKET/FRAME ASSEMBLY









WATER INLET
See page 3

A.O. SMITH WATER PRODUCTS CO., INC.

5621 W. 115TH STREET • ALSIP, ILLINOIS 60803 Phone: 1-800-433-2545 • Fax: 1-800-433-2515 Website: www.hotwater.com

PRINTED IN U.S.A. 0502 211591-000

LB/LW WATERWAYS & COMBUSTION CHAMBER PARTS LIST **Part Number** Item Description **Part Number Item Description** 17 Screw, #8-32, 3/8" Long, SST 210444 3..... Combustion Chamber Asembly 211592 18 Screw, Machine #8-32, 1" Long, SST 191770 19 Sealer, Silicone (not shown) 191482-1 5..... Coupling, Flexible w/Gasket 191780-1 21 Spacer Ring 191554-1 24 Tube Assembly, Primary (LW Models) 192388 24 Tube Assembly, Primary (LB Models) 192225 27 Washer, Flat #8 SST 191768 14 O-Ring 191556-2 15 Probe, Outlet Temp./ECO 210572 (17) **(6)** (20) (12) **LW Models** (8)LB Models


LB/LW EXHAUST, DRAIN & WATER INLET ASSEMBLY PARTS LIST				
Item Description	Part Number	Item Description	Part Number	
1 Clamp, Hose (Large)	191794-3191817-1191620191625191664191622191683-120373-18210226191556-1191626	16 Tube Assembly, Inlet (LW Models) 17 Tube Assembly, Primary (LB Models 18 Tube Assembly, Primary (LW Model 19 Tubing, Condensate	s) 192225 s) 192388 191746 191562 191938 26273 210494 191685-5 76820-18	
	24 24 25 21			

LB/LW JACKET/FRAME ASSEMBLY **Item Description** Part No. **Item Description** Part No. 1 Bolt Machine 5/16" - 18" 191358-2 2 Control Panel Assembly 210601 18 Panel, Rear (Natural) 192191 Panel, Rear (Propane) 210020 4 Frame Assembly210501-1 19 Panel, Top Cover 191609-1 5 Gasket, Display 210130 21 Screw, Hex Head 5/16" 210125 22 Screw, Hex Head #6 -32 210206 8 Junction Box Assembly 190438-1 10 Label, Control Panel210561-1 26 Support Bracket (Propane Only) 210017 12 Locknut #6 -32 210207 28 U - Bolt Assembly (Waterway) 191938 14 Nut, Lock Hex 5/16" - 18" 97896 15 Panel Assembly, Left Side 191796-3 30 Washer, Lock 191480 16 Panel Assembly, Right Side 191796-2 0


LB/LW NATURAL GAS TRAIN/BLOWER ASSEMBLY Item Description Part No. Item Description Part No. 23 Nut, Hex 1/4" 191817-1 1 Blower 192195 Blower Adapter Assembly 192215-1 24 Orifice, Air (Series 300 - Nat. Gas) 192737-3 3 Blower Manifold Assembly 192217 Orifice, Air (Series 3011 - L.P. Gas) 192737-2 25 Orifice, Union See Orifice Table Below 5 Clamp, Hose 191794-3 6 Elbow, 1-1/4" 192216 7 Elbow, Union 1-1/4" 86506-1 28 Port, Observation Upper 191572-1 9 Gasket, Blower Air Inlet 192213 30 Screw, Cap 1/4" 190960-2 10 Gasket, Burner 191564 31 Screw, Flathead #8-32 x 1/2" 191542 32 Screw, Flathead #8-32 x 3/4" 191542-1 11 Gasket, Manifold 191565 12 Gasket, Port (1/8" Thick) 191576 33 Switch, Low Gas Pressure 191149-1 14 Manifold Assembly - Air/Gas 192309 36 Tee, 1/8" 40119 15 Nipple, Close 1/8" 191147-3 16 Nipple, Close Stainless 191772-1 17 Nipple, Tapped86505-3 18 Nipple, 1-1/4" x 38 1/2" 86505-28 40 U-Bolt Assembly (Gas Train) 191938-3 19 Nipple, 1-1/4" x 28 3/4" 86505-27 20 Nipple, 1-1/4" x 2" 86505 21 Nipple, 1-1/4" x 3" 86505-2 43 Valve, Solenoid Gas 192189 22 Nipple, 1-1/4" x 4" 86505-6 **DETAIL BACK VIEW LEGENDORIFICE TABLE** Natural Propane Size Elevation Gas Gas (inches) (Feet) 192222 0.555 0-2000 2001-3000 192222-1 ---0.537 192222-2 0.533 3001-4000 192739 0.333 0-2000 192739-1 0.329 2001-3000 3001-4000 ---192739-2 0.325

LB/LW PROPANE GAS TRAIN ASSEMBLY

Item Description	Part No.	Item Description	Part No.
1 Valve, Main Gas, LP 300 Series		10 Elbow, 90 Street 1-1/4"	
2 Regulator, LP 301 Series		11 Elbow, 90 1-1/4"	
3 Valve, Firing	3423-3	12 Nipple, 1-1/4" w/Tapping	86505-32
4 Pipe Plug	3348	13 Nipple, 1-1/4"	86505-6
5 Switch, Low Gas Pressure	<u>191149-3</u>	14 Nipple, 1-1/4"	86505-4
6 Nipple, 1-1/4"	86505-13	15 Tee, 1/8" NPT Branch	192465
7 Nipple, 1-1/4"	86505-2	16 Connector, Angle 1/8"	1578
8 Nipple, 1-1/4"	86505-17	17 Bleeder, Tube	210016
9 Elbow. Union 1-1/4"	86506	18 Bleeder. Tube	192461



On LB models the circulating pump must be between the boiler inlet and the bypass (see figure below). LW models have pump mounted inside the jacket.




LB/LW BY-PASS PARTS LIST

Item	Description	Part No.
1	Ball Valve	191935
2	Tank/Pump Kit (LW Models Only - Not Shown)	210625
3	Hex Reducing Bushing (LB Only)	91940-8
4	Flush Bushing (LB Only)	192163-2
5	Relief Valve (LW Model)	
	Relief Valve (LB Model)	
	Strap, Cable (not shown)	
	Tee, Condensate	192040-1
8	Tee (For use w/relief valve):	
	LW Model	
	LB Model	
	Tee 2"x2"x2"	
	Tee 2"x2"x3/4"	
	Valve, Drain	
	Valve, Manual Shutoff	
	Vent Patch Assembly	192161
14	Nipple (For use w/relief valve)	
	LW Model	20373-12
	LB Model	92706-4
15	Clamp, Hose	191794-1

LB/LW CONTROL BOARD WHC 1502

Part Number 210128



LB/LW 1000 WIRING CHART


COLOR	GAUGE	PART NUMBER ***
White	14	41974
Black	14	99650
Green	14	41972
White	16	86580
Black	16	86578
Green	16	69058
White	18	170595
Black	18	170596
Green	18	170606
Blue	18	191719
Red	18	170603
Yellow	18	170604
Brown	18	170890
White/Red	18	191700
White/Yellow	18	191702
White/Black	18	191699
Black/White	18	191694
Yellow/Blue	18	191708
Red/Green	18	191717

^{***} Use dash number to indicate length of wire.

Example: 20 inch long red wire would be expressed as 170603-20.

WIRING AND HARNESS ASSEMBLY 99593-6 78469 191673 42573 210091 210152 99599-2

#10 Stud



16-14 Ga.

22-18 Ga.


78468

22-16 Ga.


Ignition Harness Assembly 210575




Harness Assembly 210604




Gas Valve Harness Assembly 210574-1 (Propane)



Power Harness Assembly 210579-1





Transformer Harness Assembly 210578




22-18 Ga.

Pressure Flow Switch Harness Assembly 210576





Outlet Temperature Control/ ECO Assembly 210572



Tank Probe (LW Models) 211541-1

